

Jaw Crusher Parts List 2

We support the following parts of Sandvik models. If you do not find the corresponding picture number in the following table, please contact our sales staff directly. We will give you feedback as soon as possible.

SANDVIK JAW LINERS

PART NO.	DESCRIPTION	PART NO.	DESCRIPTION
400.0485-001	FIXED JAW PLATE	400.0424-002	SWING JAW PLATE
400.0491-002	SWING JAW PLATE	400.0444-002	FIXED JAW PLATE
400.0444-001	FIXED JAW PLATE	400.0411-002	JAW PLATE
400.0443-001	SWING JAW PLATE	400.0474-02	FIXED JAW PLATE
400.0488-001	SWING JAW PLATE	400.0472-002	SWING JAW PLATE
400.0409-001	FIXED JAW PLATE	400.0473-002	FIXED JAW PLATE
400.0410-001	SWING JAW PLATE	400.0437-002	FIXED JAW PLATE
400.0463-002	FIXED JAW PLATE END	400.0433-002	SWING JAW PLATE
400.0780-002	FIXED JAW PLATE	400.0422-FE	FIXED JAW PLATE
400.0779-002	SWING JAW PLATE	400.0421-FE	SWING JAW PLATE
400.0427-002	FIXED JAW PLATE MIDDLE	400.0418-002	FIXED JAW PLATE
400.0438-002	SWING JAW PLATE	400.0417-002	SWING JAW PLATE
400.0442-002	FIXED JAW PLATE MIDDLE	J9660000	FIXED JAW PLATE
400.0440-002	FIXED JAW PLATE END	J9640000	SWING JAW PLATE
400.2207-002	FIXED JAW PLATE	10-314-404-000	CHEEK PLATE LOWER
17-201-251-001	CHEEK PLATE LOWER	10-314-386-000	CHEEK PLATE UPPER
17-201-253-001	CHEEK PLATE LOWER	400.0483-002	JAW PLATE
17-201-252-001	CHEEK PLATE UPPER	J2960000	SWING JAW PLATE
17-201-254-001	CHEEK PLATE UPPER	J2950000	FIXED JAW PLATE
400.0413-002	FIXED JAW PLATE	400.0410-002	SWING JAW PLATE

400.0408-002	SWING JAW PLATE	400.0409-002	FIXED JAW PLATE
400.0407-002	FIXED JAW PLATE	10-214-352-000	CHEEK PLATE LOWER
400.0426-002	FIXED JAW PLATE	10-214-351-000	CHEEK PLATE UPPER
400.0423-002	SWING JAW PLATE	10-314-262-000	CHEEK PLATE UPPER
J4590000	CHEEK PLATE UPPER	402.4239-01	CHEEK PLATE UPPER
J4580000	CHEEK PLATE UPPER	402.4522-01	CHEEK PLATE LOWER
J5790000	FIXED JAW PLATE	402.4521-01	CHEEK PLATE UPPER
J5780000	SWING JAW PLATE	402.4635-01	CHEEK PLATE LOWER
400.0464-002	SWING JAW PLATE	400.0964-002	FIXED JAW PLATE
400.0465-002	FIXED JAW PLATE	400.0963-002	SWING JAW PLATE
J4250000	FIXED JAW PLATE	400.0447-002	FIXED JAW PLATE
J4260000	SWING JAW PLATE	400.0446-002	SWING JAW PLATE
J4600000	CHEEK PLATE LOWER	400.0445-02	SWING JAW PLATE
J4610000	CHEEK PLATE LOWER	400.2266-002	FIXED JAW PLATE
400.0639-001	CHEEK PLATE LOWER	400.0443-002	SWING JAW PLATE
400.0739-002	FIXED JAW PLATE	402.4744-002	FIXED JAW PLATE
400.1102-002	FIXED JAW PLATE	402.4745-002	SWING JAW PLATE
400.0738-002	SWING JAW PLATE	400.0485-002	FIXED JAW PLATE
400.1101-002	SWING JAW PLATE	400.0412-002	SWING JAW PLATE
10-314-263-000	CHEEK PLATE LOWER	400.0413-003	FIXED JAW PLATE
400.0488-002	SWING JAW PLATE	400.0420-002	SWING JAW PLATE
400.0436-002	JAW PLATE	400.0422-002	FIXED JAW PLATE
400.0425-002	FIXED JAW PLATE	400.0421-002	SWING JAW PLATE

SANDVIK JAW SPARE PARTS

PART NO.	DESCRIPTION	PART NO.	DESCRIPTION
400.2870-002	FIXED JAW PLATE	400.0548-001	TOGGLE SEAT
400.2869-002	SWING JAW PLATE	10-314-512-000	LABYRINTH
400.0311-001	GUIDE	868.0522-00	ROLLER BEARING
400.0308-001	SHIM	400.0545-001	ECCENTRIC SHAFT
53-466-463-000	SHIM	10-314-515-000	LABYRINTH
53-366-419-501	RETURN ROD	868.0755-00	SLEEVE AOH
10-214-269-000	SUPPORT STRIP	868.0756-00	ROLLER BEARING
10-314-385-000	JAW WEDGE	10-215-286-500	BEARING HOUSE GUIDE
400.1331-901	RETURN ROD HEAD	53-273-771-500	BEARING HOUSE
402.4605-01	TOGGLE PLATE	400.1154-901	PISTON PIN
402.4352-01	TOGGLE SEAT	400.2382-901	HYDRAULIC CYLINDER
402.4507-01	TOGGLE SEAT	400.0753-901	HYDRAULIC CYLINDER
402.4508-01	TOGGLE SEAT HOLDER	855.0014-00	RETAINING RING SGA
J6910000	FIXED JAW WEDGE	400.0856-001	PIN
10-214-755-000	TOGGLE PLATE	400.0707-001	SIDE BLOCK
400.0450-001	SPRING	400.0707-002	TOGGLE SEAT RETAINER
400.1575-901	CYLINDER PIN	400.0603-001	TOGGLE SEAT HOLDER
53-468-758-000	FLEXIBLE WASHER	400.0549-002	TOGGLE PLATE
402.4250-00	BAFFLE PLATE	400.0549-001	TOGGLE PLATE
402.4668-01	ARMOR PLATE	400.0575-001	DEFLECTOR PLATE
400.2178-901	CLAMP RH	400.1118-001	SUPPORT BAR
10-314-356-000	JAW WEDGE	53-367-176-500	STOP LUG
402.2320-00	TENSIONING STRIP	17-201-552-501	GUIDE PIECE
402.4269-01	TOGGLE SEAT	89-242-895-000	TOGGLE SEAT

400.1680-00	TOGGLE SEAT	10-314-522-000	TOGGLE SEAT
402.4258-00	SUPPORT BAR	89-242-894-000	TOGGLE PLATE
402.4607-01	TOGGLE PLATE	10-214-355-000	SWING JAW WEDGE
402.4270-01	TOGGLE SEAT HOLDER	10-214-523-000	TOGGLE PLATE
402.4570-00	TENSIONING STRIP	488.0642-901	LOCK PLATE
402.3280-00	SUPPORT BAR	17-201-578-001	RUBBER SHIELD
400.1610-901	PROGRESSIVE FEEDER	17-201-577-001	CLAMPING BAR
10-214-535-000	TOGGLE PLATE	400.0758-001	GUIDE PLATE
17-201-650-001	TOGGLE SEAT	400.0946-901	SPRING SEAT FRAME
10-314-500-000	TOGGLE SEAT HOLDER	402.3936-00	PROTECTIVE COVER
10-114-354-000	DEFLECTOR PLATE	908.0408-00	HYDRAULIC CYLINDER
17.201.650.001	TOGGLE SEAT LOWER	402.3333-01	WASHER
400.0818-001	TOGGLE SEAT UPPER	53-366-419-503	RETURN ROD
400.0817-001	TOGGLE SEAT HOLDER	53-166-372-500	PITMAN ASSEMBLY
400.0309-001	SUPPORT BAR	402.4300-00	SPRING GUIDE
10-214-255-000	DEFLECTOR PLATE	402.4569-00	TENSIONING STRIP
10-314-246-000	JAW WEDGE	53-466-616-000	PROTECTION PLATE
53-469-936-000	FLEXIBLE WASHER	10-314-481-000	FIXED JAW WEDGE
402.4721-01	STEEL WASHER	914.0215-00	PUMP ELEMENT
402.4720-01	WASHER	400.1606-901	HOSE CONNECTIONS
400.0556-001	JAW WEDGE	402.4608-00	TOGGLE PLATE
400.0543-001	SUPPORT BAR	402.4297-90	TOGGLE PLATE
10-314-516-000	SEAL RING	868.0290-00	ROLLER BEARING
10-314-514-000	SEAL RING	10-214-384-000	DEFLECTOR PLATE
442.6470-01	SEAL RING	J5810000	JAW WEDGE
J5800000	JAW WEDGE		